

SHOREMASTER

Guide Ons

GUIDE ONS

1. Place the guide on channel over the front and/or rear rack beam.
2. Adjust to the desired width.
3. Set screw in place.

**** NOTE ****

All the set screws should be facing the middle of the rack to eliminate exposed jagged edges.

